

VOBSTER

ARCHITECTURAL

Semi-dry Stonework Repair

Open Chips

1. Clean out the chip to provide a solid key for repair material.
2. Seal the chip with a proprietary P.V.A. material to provide a good bond.
3. Mix the facing material with Castle White Cement at a ratio of (5 to 1)
4. For small chips it may well be necessary to sieve the ingredients prior to mixing
5. Ensure the repair is kept damp and protected to enable full hydration of the cement.
6. It may be necessary after approximately 3 days to locally sand the repair to lighten the colour.

Please note:

1. Do not use metal tools during the repair or surface dressing as this may well discolour the finished work.
2. Ensure protection from drying winds and direct sunlight for approximately 3/5 days.
3. When mixing the facing material ensure that the water content is kept to "earth moist" approximately 0.35% (water Cement Ratio) however this may need adjusting subject to the necessary workability.
4. We would recommend a trial repair be carried out on an inconspicuous area prior to commencement of any remedial work.